



Follow these steps to install your L.E. Wilson Case Holder Clamp onto the Trimmer Stand:

1. If you notice the threaded hole on top of the L.E. Wilson Stand, this is where the clamp mounts
2. Thread the Clamp Assembly into the threaded hole on the trimmer stand
3. Tighten the assembly with a 5/8" open end wrench or a crescent wrench
4. Place your Case Holder on the rails of the Case Trimmer
5. Swing the clamp over the Case Holder
6. To adjust the amount of pressure, adjust the lock nut with a 7/16" open end wrench or crescent wrench

Limited Warranty

All L.E. Wilson products are warranted against defective workmanship or materials under normal use for one year from the date of purchase. "Normal use" means as described in accompanying instructions. "Date of purchase" is for the first user of the product. The warranty applies only to the first user and does not cover consequential or incidental damages. If the user believes he has a defective tool he is asked to contact L.E. Wilson, Inc. P.O. Box 324 Cashmere, WA 98815 / 509-782-1328 describing the problem. The tool or part will be repaired or replaced at our option with no expense to the user except for correspondence costs. The part or tool must be accompanied by proof of purchase that shows source, date of purchase, and cost. All states have implied warranties created by law that apply to all consumers and most products so the above limitations and exclusions may not apply to you.